INSTALLATION OF GRECIAN COPING CLIPS ON POLYMER TOP CAP

Grecian clips cannot be snapped on like the straight clips The operator should cut the top cap at 22.5 degrees for each joint with the parts butted together forming the 45 degree angle. Leave a couple of feet unattached next to the jont to make it easier to flex as necessary to slide the clip on. Before attaching the top cap to the wall next to the Grecian corner slip the Grecian clip over the end of the top cap and then slip the next section of top cap into the clip. Then install the screws and cover caps approximately 1 inch either side of the clip. The process will be the same for either the open or closed polymer top cap.









